

INSTALLATION INSTRUCTIONS

Shower Cubicle Wall Panels

1. First install the Aqua Slab as directed in the installation instructions, ensuring the slab is completely level.
2. Drill holes in required location (with a hole-saw) for taps and rose.
3. Run a bead of silicone along the panel joints, and pop rivet the panels together (holes pre-drilled). Complete the assembly of the panels on the floor next to the product. Clean any excess silicone off that may be visible between the joints using water and dish washing detergent.
4. Run a beading of silicone along the edge of the slab, in front of the tile-key.
5. Lift the panels and place on the edge of the slab, in front of the tile-key.
6. Fix the panels to the wall along the top flange.
7. Fit the rose and taps.
8. Seal with silicone along the bottom edge (inside) where the panel and slab meet.
9. Fit the door & return panel following the manufacturer's instructions.